

LCD SALAT PANEL

Clock Configuration Mode:

1. Press and Hold "TIME" key to unlock time and date change settings.
2. Use "+" and "-" key to change and to save your changes press "SET" key.
3. Press "EXIT" key to exit from current mode

Clock Configuration Mode:

1. Press and Hold "UNLOCK" key to unlock iqama time change settings.
2. Use "+" and "-" key to change and to save your changes press "SET" key.
3. Press "EXIT" key to exit from current mode.

Hijri Configuration Mode:

1. Press and Hold "HIJRI" key to unlock Hijri setting.
2. Use "+" and "-" key to change and to save your changes press "SET" key.
3. Press "EXIT" key to exit from current mode.

For Theme Change:

1. Press and Hold "UNLOCK" key to unlock to configuration mode.
2. Press "MENU" key to change theme.
3. Press "EXIT" key to exit from current mode.

Note: In setting Theme Change and Iqama Configuration mode screen will be pause for few seconds to display the changes.

