

PC-MX2

User Manual

Time and Date Set:

- Press and Hold button (5) to unlock Clock.
- Seconds starts blinking. Press (+) to set the Second in "00".
- Press (SET), Hour starts blinking.
- Use (+)/(-) and set to adjust current Hour, Minutes, Date and Month.
- Press (SET) to exit.

Display Selection and Slide Duration Mode:

- Press and Hold button (MENU), Times Duration starts blinking.
- Use (+)/(-) to adjust slide duration time.
- Press (SET), Date option starts blinking. Use (+)/(-) to select desired option.
- then press (SET).
- Date Duration starts blinking. Use (+)/(-) to adjust slide duration time.
- Press (SET), Temperature & Humidity option starts blinking.
- Use (+)/(-) to select desired option.
- Then Press (SET), Temperature & Humidity Duration starts blinking.
- Use (+)/(-) to adjust slide duration time. And then press (SET).